

A decorative graphic on the left side of the slide, consisting of several overlapping, semi-transparent red chevron shapes pointing to the right, creating a sense of depth and movement.

Effect of hood size on a qualitative fit test

25th April 2018

Alison Bowry

Respiratory Protection



- Provide adequate protection
- Fit the wearers face
- To ensure the mask fits carry out a fit test

Qualitative fit test (QLFT) kits



- Hood
- Two nebulisers to produce aerosols of the
 - Sensitivity solution
 - Test solution

Standard QLFT





Standard QLFT sensitivity test

- Bitrex sensitivity solution used
- Place the hood on the wearer
- Introduce sensitivity aerosol using nebuliser
- Count the number of squirts needed for the wearer to taste the solution

HSE Operational Circular 282/28

Standard qualitative fit test

- Don mask
- Place hood over wearers head
- Introduce initial number of squirts of test solution
- Perform each exercise for 1 minute
- Introduce half the number of initial squirts at 30 second intervals
- If the wearer can taste the Bitrex then the test has failed and the mask doesn't fit

Initial number of squirts



Sensitivity result	Initial number of squirts
1-10	10
11-20	20
21-30	30
30+	-

Standard QLFT 7 exercises

- Normal breathing
- Deep breathing
- Head side to side
- Head up and down
- Talking out loud
- Bending at waist
- Normal breathing

HSE Operational Circular 282/28

Hood dimensions - standard hood



- 300mm (12") in diameter
- 355mm (14") in height
- Forms a cylindrical shape
- Internal hood space volume 20l

HSE Operational Circular 282/28

ANSI Z88.10:2010

QLFT Kits available



- Range of kits available on the UK market
- Range of hoods
- Differ in
 - Construction
 - Shape
 - Size
 - Volume



Identification of QLFT kits

- 10 commonly available QLFT kits purchased
- Three different designs of hood across the 10 manufacturers

Concerns over differing volumes

- How different are the volumes?
- Does this affect the concentration of aerosol in the hood space?
- Does this have a bearing on the quality and consistency of the fit test?

Standard Hood



Hood A




Hood A upright



Hood B



Hood C flat



Hood C shaped



Hood volumes

- Total volume of hood, calculated from its external dimensions when placed on a mannequin torso
- Volume of standard Sheffield head calculated by water immersion technique
- Volume of empty space calculated

Percentage increase of hood volumes



Hood Type	Volume of hood space when worn (L)	% increase from standard hood
Standard	20	-
A	20	0
A Upright	30	50
B	23	15
C Flat	48	140
C Shaped	44.5	122.5
	+/- 5%	
ANSI recommended hood space volume 20L		

Experimental set up



- Standard Sheffield head attached to torso
- Connected to breathing machine
 - 1.5 l @ 20 strokes per minute
 - Regular breathing at low work rate (ISO, 2004)
- Tee shirt fitted to stop the hood slipping
- Alpha Solway 3030V disposable FFP3 mask fitted (used throughout testing)

Position of sampling location



Measurement



- **TSI PortaCount**
 - Measures ambient particles/cm³
- **TSI AM150 Sidepack aerosol monitor (SPAM)**
 - Measures ambient particles mg/m³ (mass)
 - Calibrated flow rate 0.7l/min

Tests



-
- PortaCounts and SPAMs allowed to equilibrate for 2 minutes
 - 10 squirts of Bitrex test solution introduced before start of test
 - 5 squirts introduced at 30 second intervals for 7 minutes – duration of fit test
 - No attempt to simulate head movements or exercises during the test

Tests




-
- Each test was carried out on the 3 styles of hood in all configurations
 - The aerosol concentration was measured
 - Each hood configuration was tested 3 times and a mean concentration calculated

PortaCount results in hood volume order



Hood Type	Particle/cm³	Volume(L)
Standard	65782	20
A	54523	20
B	39673	23
A Upright	53341	30
C Shaped	23876	46
C Flat	18582	47

PortaCount results in hood volume order




SPAM results in hood volume order



Hood Type	mg/m³	Volume(L)
Standard	3.76	20
A	4.52	20
B	2.43	23
A Upright	3.35	30
C Shaped	1.42	46
C Flat	0.99	47

SPAM results in hood volume order



Results



-
- There is a general trend in reduction of concentration of aerosol with increasing hood size
 - A lower concentration of aerosol in the hood may lead to a fit test that is not as sensitive as required

Manufacturers



-
- Produce hoods which have a larger volume than that specified in 282/28 and recommended in the ANSI standard
 - Instructions of correct assembly of the hood is sometimes unclear
 - Instructions on the delivery of the aerosol is sometimes confusing



HSL is the commercial arm of the Health and Safety Executive, HSE. Our commercial work delivers high quality science to meet the needs of industry and government in the UK and overseas. Our commercial customers can commission services and research using our state-of-the-art scientific laboratory in Buxton, as well as analytical expertise from other parts of HSE's science base.